

50-305 Step On Tape

Is a pressure sensitive tape ideal for DIY carpet seam repairs.

It is not recommended for use with PVC or rubber backed carpets or in areas subject to large traffic volume

Application

Required Equipment

- Safety Straightedge (1-4 metres long)
- Carpet Seaming Roller
- Pile Napping Shears
- Roberts Carpet Latex Adhesive 679
- Roberts 50-305 Step On Tape

Preparing the Seam

Roberts recommend that most tufted carpets that are prone to unravel after the selvage or seam has been trimmed, be prepared for carpet seaming by applying a bead of Roberts 679 Carpet Latex Adhesive along both sides of the seam. This latex must be worked well into the raw edge and allowed to dry prior to the making of the carpet seam.

Making the Seam

1. Cut a section of Roberts 50-305 Step On Tape 75mm longer than the seam.
2. Peel the paper off the top of the tape leaving the pressure sensitive film exposed and lay the tape underneath the seam as per normal.
3. Press the carpet firmly into the pressure sensitive film and roll with a carpet seam roller.
4. A hot melt seaming iron is not required with this DIY tape.
5. When seaming has been completed be sure to trim any loose ends, taking care not to over trim as this could cause dips in cut pile carpets or a cut pile appearance in loop pile carpets.

Technical Specification

Product code	50-305 (100 meter roll) 50-306 (20 meter roll) 50-307 (5 meter roll)
Description	Step On Tape
Backing	Reversed silicone release crepe paper
Reinforcement	Fibreglass
Scrim Width	65mm approx
Roll Size	100 metres
Rolls per carton	2

Safety & Handling

Material Safety Data Sheet available upon request.

Issued: June 2007

All statements and technical information contained herein are based on tests we believe to be reliable but the accuracy thereof is not guaranteed. Users assume all risks and liability resulting from the use of this product and must confirm the suitability thereof by their own tests. Conditions of Sale contain a limited warranty against manufacturing defects.

Roberts Australia ACN 004 709 915
a division of RLA Polymers Pty Ltd
215 Colchester Road, Kilsyth, Victoria 3137, Australia
Tel: (03) 9728 1605 Fax: (03) 9728 6009



Roberts New Zealand
67 Dalgety Drive (P.O. Box 97-575)
Manukau City, Auckland, New Zealand
Tel: (9) 268 0301 Fax: (9) 268 0305

adhesives
levelling powders
hot melt tapes